

FRONT LAYER CSC AND DCOPS

REFERENCE SURFACE AND PRIMARY DOWEL CIRCLE

THEO SLM LINE

0 CONFIGURATION - NO SHIMS FOR BENDING

REFERENCE SURFACE AND DOWEL CIRCLE

SECONDARY DOWEL PIN

OUTER SENSOR

ISLAND SENSOR

ISLAND PLATE

SHIM

